

**DOUGLAS CHERO SpA**  
**FORGED VALVES**  
**dc**

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>00 - COVER SHEET</b>	Sheet / of <b>1 / 54</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	-------------------------------------	-----------------------------	----------------------------










**REMARKS FOR READING:**




Where this symbol is indicated we advise to read the section involved before performing the relevant operation



Where this symbol is indicated the reading of the section **MUST BE** done before performing any operation

**INDEX..... Sheet**

<b>Sect. 1) INTRODUCTION .....</b>	<b>1</b>
1.1) General.....	1
1.2) References .....	1
 <b>Sect. 2) RECEIVING .....</b>	<b>1</b>
<b>Sect. 3) IDENTIFICATION .....</b>	<b>1</b>
 3.1) Referring on the Plate.....	1
3.2) Referring on the Valve .....	1
 <b>Sect. 4) INSTALLATION .....</b>	<b>1</b>
4.1) Valve's removal from packing.....	1
 4.2) Installation of the valve.....	1
4.3) Gate and globe valves positioning .....	2
 4.4) Check valves positioning.....	3
4.5) Kinds of valve's connections .....	4
4.5.1) <i>Welding connection (standard)</i> .....	4
4.5.2) <i>Threaded connection (standard)</i> .....	5
4.5.3) <i>Flanged connection (standard)</i> .....	5
 4.6) Final cleaning and test operation in line .....	8
 4.7) Welding and Post Weld Heat Treatment.....	8
<b>Sect. 5) OPERATION .....</b>	<b>1</b>
5.1) Gate valve .....	1
5.2) Globe valve.....	2
5.2.1) <i>Quick Opening Globe valve</i> .....	3
5.3) Piston check valve.....	4
5.4) Ball check valve.....	5
5.5) Swing check valve .....	6
<b>Sect. 6) ORDINARY MAINTENANCE .....</b>	<b>1</b>
6.1) Stem lubrication.....	1
6.2) Gasket substitution .....	1
6.2.1) <i>Ordinary maintenance to Quick OpeningGlobe valves – Gasket substitution</i> .....	2
  6.3) Packing ring addition .....	4

	<b>Sect. 7) EXTRAORDINARY MAINTENANCE</b> .....	<b>1</b>
	7.1) Body/bonnet disassembly .....	1
	7.2) Seats repair and/or substitution.....	1
	7.2.1) <i>Seat and/or disk repair</i> .....	1
	7.2.2) <i>Seat replacement</i> .....	2
	7.3) Seat repair and/or substitution .....	4
	7.3.1) <i>Seat/disk repair</i> .....	4
	7.3.2) <i>Seat/disk replacement</i> .....	5
	7.3.3) <i>Seat and/or disk repair of Quick Opening Globe valves</i> .....	6
	7.3.4) <i>Seat/Disk replacement of Quick Opening Globe valves</i> .....	7
	<b>Sect. 8) REPLACEMENT PARTS REQUEST</b> .....	<b>1</b>
	<b>Sect. 9) RESUMING TOOLS LIST</b> .....	<b>1</b>
	9.1) Assembly/Disassembly of Body screws (Class 150÷1500c).....	1
	9.2) Assembly/Disassembly of Body stud bolts (Class 1500÷2500) .....	2
	9.3) Assembly/Disassembly of Gland nuts (all Class).....	3
	9.4) Assembly/Disassembly of Handwheel nuts (Gate valves) .....	4
	9.5) Assembly/Disassembly of Handwheel nuts (Globe valves) .....	5
	9.6) Assembly/Disassembly of Body seat (Globe valves, Ball and Piston check valves) .....	6
	9.7) Assembly/Disassembly of Stem nut (Globe valves).....	7
	9.8) Other tools and accessories.....	8
	<b>Sect. 10) APPENDIX</b> .....	<b>1</b>
	10.1) Gaskets dimensions .....	1
	10.2) Packings dimensions.....	2
	10.3) Hydraulic and pneumatic tests .....	3
	10.3.1) <i>Gate valves</i> .....	3
	10.3.2) <i>Globe valves</i> .....	3
	10.3.3) <i>Check valves</i> .....	4
	10.3.4) <i>Quick Opening Globe valves</i> .....	4
	10.3.5) <i>Applicable Test Pressures</i> .....	4
	10.4) Employment Limits .....	5
	10.5) CV Values.....	8
	<b>Sez. 11) Instruction for use of the valves in Potentially Explosive Atmospheres (ATEX)</b> .....	<b>1</b>
	11.1) Service temperature .....	1
	11.2) Opening and closing operations of manual valves .....	1
	11.3) Fluid leakage.....	2
	11.4) Opening and closing operations of a motor operated valve .....	2
	11.5) Dust cleaning-up .....	3
	11.6) Removal of the valve components .....	3
	11.7) Identification of the equipment .....	3
	11.8) Safety instruction for installation,operation & maintenance in hazardous area ..	4

## 1.1) General

All information contained in this manual can be applied to all valves manufactured by DOUGLAS CHERO S.p.A.

DOUGLAS CHERO valves respect construction conditions, materials and working conditions request in order by the Customer or by International Standards that can be applied (API, BS, ASME, MSS, ecc...).

This manual recollects the indications given by BS 6683: Installation and Use of Valves.

Douglas Chero forged valves are built with carefully selected materials to permit, in conditions of correct installation, a long use without interventions.

Minimum attention and correct maintenance can extend their life and use.

For the most part maintenance and repairs can be carried out on site.

For bigger interventions we suggest you to send the material back to the factory for an inspection and/or rework.

Douglas Chero can modify without previous advice the contents of this manual for production and working improvement.

## 1.2) References

Eventual shipping of material will have to be sent to the following address:

### **DOUGLAS CHERO SpA**

Località Pradaglie

29013 - Carpaneto P.no (PC) - ITALY

Phone.: 0523/854011

Fax: 0523/850389

E-Mail: [webmaster@douglas-cherо.com](mailto:webmaster@douglas-cherо.com)

Web Site: [www.douglas-cherо.com](http://www.douglas-cherо.com)

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>01 - Introduction</b>	<i>Sheet / of</i> <b>1 / 1</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	---	-----------------------------------	-----------------------------------

## 2) RECEIVING

Unless requested otherwise, shipped material is packed in wooden cases lined with tarred paper and between each layer of valves corrugated cardboard. This kind of packing permits to satisfy normal transport needs, guaranteeing a good resistance against humidity.

All kinds of valves have sufficient protection for storage in a closed environment for a maximum period of 6-8 months.

This protection is, unless otherwise specified, a rust preventative by phosphatizing treatment on forged parts (not stainless) and plastic plugs on body's ends.

Valves are shipped in closed position to protect parts during transport.

As soon as received, valves should be controlled to verify if there are any problems due to transportation. If the protective plugs are taken off for inspection purposes, make sure that they are replaced to maintain a clean inside to the valve.




If plugs should be missing we suggest you to control the cavity.

All foreign material possibly present will have to be removed.

If it is required to clean the inside of the valve, make sure about the kind of solvent to be used, especially if the valve has to be installed in the line by welding.

Upon receipt of any valves you have to check that there are the following documents:



- The Packing List
- The Instruction Manual
- The certificates, if expressly requested that they must not be attached to the valves, are put on the cases or attached to the Packing List.


### 3) IDENTIFICATION

#### 3.1) Referring on the plate

The valve identification plate is positioned, as in the picture, on the handwheel top side (in gate and globe valves) and on the cover top side (in check and piston/ball and swing).



The valve's class (rating), the minimum and maximum working temperatures and the maximum working pressure must be checked before installation.



#### 3.2) Referring on the valve




Referring on the valve can assume a different position, that depends on type and construction.

In general we can indicate the following rules (see the following picture):

- A) Number indicating the **Primary Working** pressure in Lbf/in<sup>2</sup> or Class (ex.: **800**)
- B) Symbol indicating the **Nominal Dimension** of the valve (ex.: **Ø 1.1/2**)
- C) Symbol indicating the **Rough Supplier Code** and the **Rough Casting Code** normally separated by a space or a dash (ex.: **FA-CC** or **FA CC**)
- D) Symbol indicating **Body/Bonnet/Cover Material's Quality**: by symbology ASTM (ex.: **F316L**)

All the above description are normally taken from forging during the pressing.

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>03 - Identification</b>	Sheet / of <b>1 / 2</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	--	----------------------------	----------------------------





## 4) INSTALLATION

Some necessary condition for installation:

- ⇒ use proper tools
- ⇒ make you sure that the connection valve-line is correct
- ⇒ make you sure that the direction of the arrow, pressed on the body valve, coincide with flowing of the fluid in the line (not necessarily for gate valves).

### 4.1) Valves removal from packing

Before removing the valve please verify the weight shown on the drawings. If necessary use suitable lifting equipment.

The valve should be taken out from the packing only at the stage of the installation in the line, to avoid any unnecessary damage.

Please do not drop the valve to avoid damages at the connections and on the stem, which can be subject to deformation.

In the event of these circumstances please ask for the replacement of the valve, since it may not be suitable for proper usage at the maximum safety limit.



### 4.2) Installation of the valve

Before the valve is installed, verify that there is enough space around the valve, for easy operation.

Consider the necessity of space for possible repairing and/or substitutions.

Make you sure you have removed the protection plugs and you have verified that the valve is clean inside.

Anywhere that it is possible clean the part of line connected to the valve with compressed air (or water) to take away possible traces of dust or dirt.

Tight the packing nuts before starting.

Lubricate the stem/stem nut as follow, using a right quantity of grease: for valves without greaser, the valve must be opened, put the grease on the upper stem and close the valve; for valves with greaser, use the greaser to lubricate the stem. Remarks: Grease must be according to the Customer's specifications.


After the installation remove any foreign material from the line.

The valves can not be installed on the pipeline with one end directly opened in atmosphere.

If the valves should be used at the end of the line, with one end opened in atmosphere, this must be specified at the bidding stage.

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>04 - Installation</b>	Sheet / of <b>1 / 9</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	--------------------------------------	----------------------------	----------------------------

## 4.3) Gate and globe valves positioning




These valves should be installed, where it's possible, on horizontal line, with the stem upwards. It is accepted that a position between vertical and horizontal guarantees a correct drainage.

If stem position is below the horizontal line there will be settings of material in the bonnet cavity that could have effects on the valve correct working.


It's also possible installing the valve in vertical lines. Gate valves can be put without worrying about the flow direction.

As far as it concerns globe valves, we recommend you that pressure always come from the bottom hole passage, in this way pressure doesn't work on the packing when the valve is closed.

For installation of Quick Opening Globe valves, you must make sure that there is space enough for the manoeuvre of the lever.




## 4.4) Check valves positioning



These valves too should be put along horizontal lines with cover towards the up side.

Possible variations along the vertical axis shouldn't be over 5°.


Swing or piston/ball executions with return spring can be adjusted to other installations, for example in vertical position with the flow going upward.




Never install check valves along vertical lines with the flow direction towards down or along horizontal lines with cover bent in an axes not bigger than 5° on the vertical. Instal always the check valves in the direction indicated by the arrow on the body.

**4.5) Kinds of valve's connections****4.5.1) Welding connection (standard)**

- SW ends groove and tongue - SW (according to ASME B16.11)



- BW ends to be welded of the head - BW (according to ASME B16.25)



These connections must have an appropriate welding that could guarantee resistance at pressure.

Remember that valves, pipes and junctions and any other accessories inserted by welding along the line must be in compatible material and the person doing the welding must be qualified.

Make you sure you have left 1,5 mm of space between the end of the line pipe and the bottom valve SW end or the head end to be welded; this permits a correct expansion of the material during the welding.

Remember that the body valve is compact and there's a short distance between extremities, any long welding could cause that the valve gets too warm and this causes damages to joint parts and/or distortion of the areas.

To avoid this problem we suggest you to let the parts to get cold, alternating it with two near valves.


When you are welding directly on the line make you sure that the valve is in position nearly closed.

Immediately after the welding make you sure that the valve works in a correct way, to prevent a possible sizing of the joint parts.

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>04 - Installation</b>	Sheet / of <b>4 / 9</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	--------------------------------------	----------------------------	----------------------------

#### 4.5.2) Threaded connection (standard)

- Threaded NPT ends groove/tongue - NPT (according to ASME B1.20.1)



A particular care must be given to this kind of connection too. Make an inspection of all the threads before assembling.

Use a proper material for threads. Put it always on the thread that is outside, never on the one that's inside.

Too much material on the outside thread would be expelled outside by the valve, meanwhile in the inside thread would be expelled in the cavity, making the elimination difficult.


When you assemble valves with this kind of NPT ends on the line, don't bolt forcing on the bonnet.

Use a proper tool to turn pipes, one to move the body valve and another for the line pipe.

#### 4.5.3) Flanged connection (standard)


-Raised Face Flange - RF (ASME B16.5)

Must be installed with equal RF flanges as the line.




- Joint Ring Flange - RJ (ASME B16.5 and ASME B16.20)

Must be installed with equal RJ flanges as the line.




- Small Female -SF / Large Female LF (ASME B16.5)

Must be installed with complementary flanges SM or LM on the line.




- Small Male flange SM / Large Male LM (ASME B16.5)

Must be installed with complementary flanges SF or LF on the line.




- Small Groove Flange -SG / Large Groove LG (ASME B16.5)

Must be installed with complementary flanges ST or LT on the line.



- Small Tongue Flange -ST / Large Tongue -LT (ASME B16.5)

Must be installed with complementary flanges SG or LG on the line.



Before the assembly, make you sure that the flanges valve/line are JK of the same type or, in any case, complementary.

Do the assembly of the flanged joint as specified here:


- ① Tight with little force the nuts with cross action. This first tightening will be repeated more times to avoid flanges deformation and irregular pressure on the gasket.
- ② Repeat the previous passage using more locking force until you have the correct locking of all nuts. It could be necessary repeating this passage more times, because, when you lock a nut, there's normally a traction reduction on the nut next to it.
- ③ In applications where high pressure and/or temperature is used, we recommend to control again the correct locking joint 24 hours after installation just to correct possible settlements.

#### 4.6) Final cleaning and test operation in line

After having completed the installation, handle the valve permitting or stopping the flow, to eliminate every possible trace of foreign material.

Verify, when it can be applied, the correct tight of body/bonnet connection and the correct tight of the nuts gland.

Control that you handle the valve in the correct way. The test under pressure guarantees the whole joints integrity.



The backseat on the stem has to be considered as a mean of determination for the complete opening of the valve. As there's less surface of contact in the untightness area, you shouldn't apply too much force in opening.



Consider that valves with stem, kept for long in the same position, can make the handling worse, with sizing of packing and loss of lubrication in the stem thread. That's why we suggest scheduling opening/closing operations.



#### 4.7) Welding and Post Weld Heat Treatment

The valves must be semi-opened in case of welding.

The maximum attention should be paid not to overheat the body/bonnet coupling of Bolted Bonnet valves in order to protect the gasket and the packing in the Stuffing Box (both for Welded and Bolted Bonnet valves).

Where post weld heat treatment for the relieving of welding should be performed, the same have to be localised only on the welding area, for the reasons stated at point above.

Anyway, the heating of the body valve should not be over 600°C, in order not to damage the body and disk seat.

The valve must be semi-opened.

Please always verify that the material of packing and gasket is suitable for the temperature reached during the operations.

As far as the post weld heat treatment, please take as guide line the table of the maximum temperature to which the gasket and packing can be subject on the basis of the material used.

The following table shows the more common materials.

Further information regarding materials not included in the said table, are available upon request to Douglas Chero S.p.A.

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>04 - Installation</b>	Sheet / of <b>8 / 9</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	--------------------------------------	----------------------------	----------------------------

Material □	Packings		Gaskets	
	Max. Temperature	Type	Max. Temperature	Type
PTFE	200°C	PT5504/S	200°C	316+PTFE
Graphoil	900°C	V48/E+GR8800	700°C	316+Graphoil
Flexna	400°C		300°C	316+Fiber

Please note that the maximum temperature applicable to the gasket, is always the same, irrespectively from the material used for the metallic spiral.

## 5) OPERATION

### 5.1) Gate valve

The flow through this type of valve is controlled by the movement of the disk (13) between two seats (14).

The bottom stem end (12) is jointed with the top part of the disk (13); that permits the necessary dragging for the manoeuvre.

The disk (13) is guided in all its run by a groove in the body valve (10).

Seats (14) are locked in their position by a rolling.

The stuffing box, containing the packing rings (23), is in the bonnet (11).

The packing (23) is pressed in the stuffing box by the gland (15) and by the flange gland (16) that exerts the necessary pressure by two tight rods (20) by four gland nuts (21).


The threaded top part of the stem (12) is united with the stem nut (17), which is locked in its seat by the stem nut (19).

The valve opens itself turning the handwheel (18) in counter-clockwise.

After the valve has been completely open, turn of one quarter towards the closing point, so that the valve doesn't remain in backseat position.

Never act with too much effort on the handwheel, the stem and the tight surface could be damaged (if there were foreign material).

The following picture shows a gate valve in normal operation, but the way of working can be applied, with few operations, to all other variants.



## 5.2) Globe valve

Globe valve construction is similar to the gate valve one, and the operation way is in general the same.

The difference consists in the different flow control systems, which in globe valve is applied by a disk (13).

Other executions, can be given if asked, consider a parabolic form, needle with inserts of Teflon.

The disk (13) is normally in couple with stem (12), by an elastic ring, which guarantees the adherence to the seat without permitting the separation of the stem (12).

As the fluid does not flow in a straight course, the globe valve has a considerable loss of load.


It is however an excellent means of regulation, especially in the control of moderate-full passage.

As gate type, these valves too can be open turning the handwheel (18) counter-clockwise.

After the valve has been completely open, turn of one quarter towards the closing point, so that the valve cannot be in backseat position.

Never apply too much force on the handwheel, because stem and tight surfaces could be damaged (in case there would be foreign material).

The following picture shows a globe valve during normal operation, but the working way can be applied, with few exceptions, to all other variants.



### 5.2.1) Quick Opening Globe valve


Quick Opening Globe valve construction is similar to the gate valve one, and the operation way is in general the same.

The difference consists in the different flow control systems, which in globe valve is applied by a disk (13).

The disk (13) is integral to the stem.

As the fluid does not flow in a straight course, the globe valve has a considerable loss of load.

In spite of globe valves, these are opened by means of a lever.



### 5.3) Piston check valve

The piston check valve body (10) is the same as the globe valve. In this case it is a piston (13) guided in the body valve, which controls the fluid acting against the seat (14).


The piston (13) remains in touch with the seat (14) for gravitational force and opens itself when the fluid passes through the bottom part.

The fluid entering in the opposite sense, instead, forces the piston (13) against the seat (14), stopping the passage.

The piston check valve is mainly used on horizontal lines.

It can be however used on vertical lines, by putting a return spring (28) on the piston (if not specified in a different way, the return spring is always installed).

The following picture shows a piston check valve in normal operation, but the way of operation could be applied, with few exceptions, to all other variants.




### 5.4) Ball check valve

This construction is the same of the type described right now, only the piston is substituted by the ball (13).

The cover, with a proper guide system, limits the ball (13) movements giving it a direction towards the seat (14).

As for the piston type, the ball check valve too can be used on vertical lines, using a return spring (28) if not specified in a different way, the return spring is always installed).

The following picture shows a ball check valve in normal execution, but the working way can be applied, with few exceptions, to all other variants.



### 5.5) Swing check valve

This type of check valve with straight passage is composed by a swing (13), which remains against the seat (14) in resting condition.


The swing is fixed at another hinge (31) which is fixed by a pin (32) at a rod (30) bolted at the cover (11).

When the flow passes in the direction indicated by the arrow, the pin permits the swing/hinge group (13/31) to turn leaving the seat (14).

An opposite direction passage makes the swing (13) going towards the seat (14) locking the flow.

The swing check valves are preferred to be installed on horizontal lines, but they can, however, be used on vertical lines with the flow arrow upward.

The following picture shows a swing check valve in normal execution, but the working way can be applied, with few exceptions, to all other variants.



## 6) ORDINARY MAINTENANCE

Ordinary maintenance of a valve consists generally in the stem/stem nut lubrication, in packing ring addition and in gaskets substitution (if there are any).

### 6.1) Stem lubrication

Stem nut and stem threaded parts must be lubricated periodically according to working conditions, however not less than once a year.

We recommend the use of a lubricant liquid or in any case one that is very fluid.

Graphite dust can be applied by spray or, if not available, by a simple brush.

### 6.2) Gasket substitution

The procedure that has to be followed to substitute the gasket (where there is one), is indicated in the following lines.

The phases indicated in the pictures are referred to a gate valve, but this application can be done on globe valves as well. For check valves it can be done substituting the picture of the bonnet with one of the cover:

- 1) Isolate or depressurise the part of the line, working with the valve in nearly-open position;
- 2) Mark a side of the body/bonnet (or cover) so that you can return at the starting position where you do the final assembly. This operation is very important because it guarantees the tightness among the same surfaces. Unscrew and remove the body nuts;
- 3) Take the assembled bonnet off and mark the side of the disk (not on the tightness side). Remove and eliminate the old gasket;
- 4) Control the gasket surfaces that are in contact, just to verify a possible damage or deterioration. Clean the areas and take away any foreign material and/or residue. Clear the gasket seat with a rough cloth. Every possible ruling on the tightness gasket surface can cause a loss. To obtain a good tightness, the surfaces in touch must have a roughness between 1,6 and 3,2 Ra;
- 5) Install the new gasket without using any sealing material during this substitution;
- 6) Reassemble the valve, making you sure that the disk is not in contact with the seat. Locking values of the body nuts will have to follow in general this list:


1/2"R	1/4"F	3/8"F	M10	40 ÷ 45 Nm
3/4"R	1/2"F		M10	40 ÷ 45 Nm
1"R	3/4"F		M12	50 ÷ 55 Nm
1.1/4"R	1"F		M12	55 ÷ 60 Nm
1.1/2"R	1.1/4"F		M14	65 ÷ 75 Nm
2"R	1.1/2"F		M16	85 ÷ 95 Nm
2"F			M20	130 ÷ 145 Nm


### 6.2.1) Ordinary maintenance to Quick Opening Globe valves - Gasket substitution

Ordinary maintenance of a Quick Opening Globe valve consists generally in packing ring addition and in body/bonnet gaskets substitution.


- 1) Isolate or depressurise the part of the line;
- 2) Mark a side of the body/bonnet (or cover) so that you can return at the starting position where you do the final assembly. This operation is very important because it guarantees the tightness among the same surfaces;
- 3) Unscrew and remove the spacer which takes pressure on springs (1). During this operation the stem of the valve must be kept steady;
- 4) Remove the plug at the valve's bottom (2) then take away the stem (3);
- 5) Remove and eliminate the old gasket. Unscrew and remove the body nuts;
- 6) Control the gasket surfaces that are in contact, just to verify a possible damage or deterioration. Clean the areas and take away any foreign material and/or residue. Clear the gasket seat with a rough cloth. Every possible ruling on the tightness gasket surface can cause a loss. To obtain a good tightness, the surfaces in touch must have a roughness between 1,6 and 3,2 Ra;
- 7) Install the new gasket without using any sealing material during this substitution;
- 8) Reassemble the valve. Locking values of the body nuts will have to follow in general the list in section 6.2).

### EXAMPLE FOR DISASSEMBLING OF GATE VALVES (APPLICABLE ALSO TO GLOBE AND CHECK VALVES)





**EXAMPLE FOR DISASSEMBLING OF QUICK OPENING GLOBE VALVE**




### 6.3) Packing ring addition

When a cool valve is being opened to permit the passage of vapour or anyway a fluid/gas at high temperature, there could be a loss through the packing. Do not lock immediately the bolted gland, but wait for the valve can reach the temperature of operation. Generally the loss stops in a few minutes.

If the loss goes on, consult the following part of this section.


The loss through the stuffing box not always indicates a valve with defects: it could be necessary to have a higher pressure on the packing, acting on bolted gland.

A too high locking can cause difficulty in handling and a possible damage at the stem.



If the gland is at the end of run, or if a too high locking on bolted gland does not block the loss, isolate it and under pressure re-pack it.

It is not necessary to take the valve out of the line for this operation, it is however essential that the valve is not working and that the stem is in the backseat position.



Before doing this, make certain that the valve has really depressurised that part of line, especially if you are working on dangerous flows.

Remove the packing, remove the gland nuts and make the largest space possible between the gland and the stuffing box flange. Remove the old packing using a proper tool. Any remaining part of the old packing has to be eliminated from stems. Clean the stem and the stuffing box verifying if there is any possible damage. Install new packing rings, one at a time, 90° far from the other. Each new ring must be correctly pushed in seat before putting the other one. Lower the gland and the flange against the packing, reassemble and lock correctly the gland nuts.

## 7) EXTRAORDINARY MAINTENANCE



Procedures described in this chapter have to be used only if there is absolute necessity. If repairs below mentioned do not answer at an immediate emergency, please return the damaged valve to the factory.

### 7.1) Body/bonnet disassembly

In these following lines is described how to disassemble body/bonnet. Remember that the following operation must be done only if the valve operates badly and it must be done by experienced trained personnel.

- ⇒ For bolted body/bonnet valves:  
Back to paragraph 6.2: gasket replacement.
- ⇒ For welded body/bonnet valves: welding will be removed by a portable wheel or something similar. Welding elimination will be as more reduced as possible. At the end, screw the bonnet group off, trying not to damage the disk. Remember to remove the bonnet screws counter-clockwise.

### 7.2) Seat repair and/or replacement

Valve construction and seats repair/installation make it necessary to take the valve off the line, before doing this operation.

That is why we recommend to return the valve to the factory (where possible) for replacement or repair. In case of emergency we show in these following lines, how to replace and/or how to repair where it is.

#### 7.2.1) Seats and/or disk repair


For valves with a diameter between 1" and 2", if seats are not too damaged, repair can be done directly on body, by polishing.

Bottom dimensions can be repaired too, but with difficulty. We recommend, in this case, to replace the seat.

Seats can be polished in body using a tool composed of a circular plate and a T-pin.

The following picture can show, more or less, the type of tool that should be used.

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>07 - Extraordinary Maintenance</b>	Sheet / of <b>1 / 7</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	---	----------------------------	----------------------------




Disks can be polished on every plane surface, but trying to keep the correct wedge ( $10^\circ$  at the axis).

### 7.2.2) Seats replacement

Seats should be removed by a proper cold chisel, suitable for the valve dimension, in any standard material available on market. During this operation, the operator must take care in order not to damage any body machined surface.

Act alternatively between the central hole and the body ends, as shown in the following picture:



Before proceeding with the operation, make you sure that body and seats interested surfaces are clean and without foreign materials.

Then seats must be introduced by the top opening of the body, with the top part (thin) in the center upward (look at the picture at the end of the paragraph).

It is necessary to have enough space to work without problem around the valve body.

Put on seat connection surface a small quantity of grease, to help to be adjusted.

Insert the disk using a false-stem.

Disk-seat group bond can be done by hammering the end of the false-stem.

Control that the disk and seats are in line and that the false-stem is centered in the body hole.

Keep the false-stem to force the disk in position.

Now it is ready for a new test of contact between the jointing surfaces; this test can be done using the necessary force on the disk, to leave its impression on seats.

Remove the disk and, if you have a uniform impression, the valve is ready to be reassembled.

Do not remove seats after this test.


Assemble the valve, with gasket, then force the disk in closing position. Now the valve is ready for seats rolling.

When using the pin, put the valve on something stable, lubricate the pin expansion cone to avoid seizing-up.

Push the pin in the ends hole up to the complete expansion of the seats border.

Repeat the operation on the other side taking care not to expand them too much.

Set the disk free and then inspect the job, and if expansion has been correct, the valve is ready for the pressure test.



### 7.3) Seat repair and/or substitution

These notes can be applied both on bolted seat and stellite integral seat.

Both can be repaired (bolted seats can be easily substituted too).

#### 7.3.1) Seat/disk repair

The following description normally concerns globe valves.

For check and piston ball valves we suggest the substitution of the interested parts, if a simple seat and/or piston polishing is not enough.


If the defect on the disk conical part is great, disassemble the assembled stem.

Put the assembled stem on the roll of a turning table, centering the jaws on the exterior surface of the disk.

Block the jaws to assure that the conical surface is centered with the roll axis. Turn the cone for a minimum depth necessary to eliminate the defect.

Polish, if necessary, with sandpaper.

Then pass at the following operation described below.



When the defect on the surface has been reduced, the surfaces in touch can be taken to the origin by lapping.

Apply a small quantity of an abrasive product among the parts that both turn in alternative direction.

Do this operation until the defect is completely disappeared.

At the end we suggest to verify with blue colour, the perfect grip of parts.

For a correct use of the jointing parts, we suggest to do the operation described above, with seat installed in body, turning the stem/disk by means of the assembled handwheel as in the picture.

### 7.3.2) Seat/Disk replacement

Bolted seat can be replaced with valve body in working position, but isolated from the line.

The inside area of the seat is hexagonal and needs a proper wrench for replacement, as described in 9.6 paragraph Seat/body assembly/disassembly.


Take off the seat that has to be replaced and control carefully the body thread, to see if it's in good conditions.

After having bolted the new seat into the body, take it away to verify the support surface contact.

Then bolt it.

In globe valves the disk must be substituted with the stem, because it is not possible their separation.

The disk only, instead, can be replaced if there are previous executions as a "T" attaches and a threaded nut attaches as in the picture.



In ball and piston check valves the damaged disk can be easily taken off to be replaced.


7.3.3) Seat and/or disk repair of Quick Opening Globe valves

The following description normally concerns globe valves.

If the defect on the disk conical part is great, disassemble the assembled stem.

See section 6.2.1) for disassembling of the Stem/Disk.

Put the assembled stem on the roll of a turning table, centering the jaws on the exterior surface of the disk.



Block the jaws to assure that the conical surface is centered with the roll axis. Turn the cone for a minimum depth necessary to eliminate the defect.

Polish, if necessary, with sandpaper.

Then pass at the following operation described below.

When the defect on the surface has been reduced, the surfaces in touch can be taken to the origin by lapping.

Apply a small quantity of an abrasive product among the parts that both turn in alternative direction.

Do this operation until the defect is completely disappeared.

At the end we suggest to verify with blue colour, the perfect grip of parts.

For a correct use of the jointing parts, we suggest to do the operation described above, turning the stem/disk with seat of the body.

#### 7.3.4) Seat/Disk replacement of Quick Opening Globe valves

On Quick Opening valve, in case of bolted seat it can be replaced with valve body in working position, but isolated from the line.

The inside area of the seat is hexagonal and needs a proper wrench for replacement, as described in 9.6 paragraph Seat/body assembly/disassembly, except that the operation must be performed in the bottom part of the body (see section 6.2.1 for disassembling of the plug under the valve and of the stem/disk).

Take off the seat that has to be replaced and control carefully the body thread, to see if it's in good conditions.

After having bolted the new seat into the body, take it away to verify the support surface contact.

Then bolt it.

In globe valves the disk must be substituted with the stem, because they are in a single piece (integral stem/disk type).

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>07 - Extraordinary Maintenance</b>	<i>Sheet / of</i> <b>7 / 7</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	--	-----------------------------------	-----------------------------------

## **8) SPARE PARTS REQUESTS**

Normally replacement parts are packing and gaskets, that can be more easily damaged during the valve service, because of their material composition.

If they concern normal production they can be normally shipped from stock. Where it is allowed by production, many parts of the valve are interchangeable.

When there is an order of replacement parts, we ask you to make reference to the identification plate for the following features:

- ⇒ catalogue number,
- ⇒ type, dimension, series,
- ⇒ material,
- ⇒ your code, if possible.

Wherever possible, the original order and its date can help for material identification, especially for special valves.


Consider that in many cases, it can be asked an offer for replacement parts, transmitted with order technical documents, which contain those necessary information.

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>08 - Spare Parts Requests</b>	<i>Sheet / of</i> <b>1 / 1</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	---	-----------------------------------	-----------------------------------

## 9) RESUMING TOOLS LIST

### 9.1) Assembly/Disassembly Body screws (Class 150÷1500c)

The wrench can be open or close type




	Ch (mm)			
	150÷800		1500c	
1/2"R	<b>14</b>	17 (*)	<b>14</b>	17 (*)
3/4"R	<b>14</b>	17 (*)	<b>17</b>	19 (*)
1"R	<b>17</b>	19 (*)	<b>17</b>	19 (*)
1.1/4"R	<b>17</b>	19 (*)	<b>19</b>	22 (*)
1.1/2"R	<b>19</b>	22 (*)	<b>22</b>	24 (*)
2"R	<b>22</b>	24 (*)	<b>27</b>	30 (*)
1/4"F	<b>14</b>	17 (*)	-	-
3/8"F	<b>14</b>	17 (*)	-	-
1/2"F	<b>14</b>	17 (*)	-	-
3/4"F	<b>17</b>	19 (*)	-	-
1"F	<b>17</b>	19 (*)	-	-
1.1/4"F	<b>19</b>	22 (*)	-	-
1.1/2"F	<b>22</b>	24 (*)	-	-
2"F	<b>27</b>	30 (*)	-	-

(\*) Nuts

**9.2) Assembly/Disassembly Body stud bolts (Class 1500-2500)**


The wrench can be open or close type



	Ch (mm)	
	1500	2500
1/2"R	-	-
3/4"R	-	-
1"R	-	-
1.1/4"R	-	-
1.1/2"R	-	-
2"R	-	-
1/4"F	-	-
3/8"F	-	-
1/2"F	<b>17</b>	<b>17</b>
3/4"F	<b>19</b>	<b>19</b>
1"F	<b>22</b>	<b>22</b>
1.1/4"F	-	-
1.1/2"F	<b>27</b>	<b>27</b>
2"F	<b>27</b>	<b>27</b>

**9.3 Assembly/Disassembly Gland nuts (all class)**


The wrench can be open or close type



	Ch (mm)			
	150÷800	1500c	1500	2500
1/2"R	13	13	-	-
3/4"R	13	13	-	-
1"R	13	17	-	-
1.1/4"R	17	17	-	-
1.1/2"R	17	17	-	-
2"R	19	19	-	-
1/4"F	13	-	-	-
3/8"F	13	-	-	-
1/2"F	13	-	13	13
3/4"F	13	-	17	17
1"F	17	-	17	17
1.1/4"F	17	-	-	-
1.1/2"F	17	-	24	24
2"F	19	-	24	24

**9.4 Assembly/Disassembly Handwheel nuts (Gate Valves)**


The wrench can be open or close type



	Ch (mm)			
	150÷800	1500c	1500	2500
1/2"R	19	24	-	-
3/4"R	19	24	-	-
1"R	24	30	-	-
1.1/4"R	30	32	-	-
1.1/2"R	32	32	-	-
2"R	32	36	-	-
1/4"F	19	-	-	-
3/8"F	19	-	-	-
1/2"F	19	-	30	30
3/4"F	24	-	32	36
1"F	30	-	32	36
1.1/4"F	32	-	-	-
1.1/2"F	32	-	50	50
2"F	36	-	50	50

**9.5) Assembly/Disassembly Handwheel nuts (Globe Valves)**


The wrench can be open or close type



	Ch (mm)			
	150÷800	1500c	1500	2500
1/2"R	10	13	-	-
3/4"R	10	13	-	-
1"R	13	17	-	-
1.1/4"R	17	17	-	-
1.1/2"R	17	17	-	-
2"R	17	19	-	-
1/4"F	10	-	-	-
3/8"F	10	-	-	-
1/2"F	10	-	17	17
3/4"F	13	-	17	19
1"F	17	-	17	19
1.1/4"F	17	-	-	-
1.1/2"F	17	-	24	24
2"F	19	-	24	24

**9.6) Assembly/Disassembly Body seat (Globe Valves, Ball and Piston Check Valves)**


The wrench must be "T" type



	Ch (mm)			
	150÷800	1500c	1500	2500
1/2"R	8	-	8	-
3/4"R	12	-	12	-
1"R	16	-	16	-
1.1/4"R	19	-	19	-
1.1/2"R	22	-	22	-
2"R	26	-	26	-
1/4"F	8	-	-	-
3/8"F	8	-	-	-
1/2"F	12	-	8	8
3/4"F	16	-	12	12
1"F	19	-	16	16
1.1/4"F	22	-	-	-
1.1/2"F	26	-	22	22
2"F	40	-	26	26

**9.7) Assembly/Disassembly Stem Nut (Globe Valves)**

The wrench must be open type



	Ch (mm)			
	150÷800	1500c	1500	2500
1/2"R	19	22	-	-
3/4"R	19	22	-	-
1"R	22	30	-	-
1.1/4"R	27	30	-	-
1.1/2"R	30	30	-	-
2"R	30	34	-	-
1/4"F	19	-	-	-
3/8"F	19	-	-	-
1/2"F	19	-	27	27
3/4"F	22	-	30	34
1"F	27	-	30	34
1.1/4"F	30	-	-	-
1.1/2"F	30	-	46	46
2"F	34	-	46	46

**9.8) Other tools and accessories**

Wrenches and tools are available for valves maintenance:


- Tools to take packing rings off;
- Combination of oil/greases for lubrications, compounds for lapping and fine sandpaper to lap or clean different surfaces;
- Pipe wrench for threaded ends valves installation;
- Chisels, rolling pins, false-stem for repairs;
- Other accessories and tools recalled in this manual.

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>09 - Resuming Tools List</b>	<i>Sheet / of</i> <b>8 / 8</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	--	-----------------------------------	-----------------------------------

**10) APPENDIX**

**10.1) Gaskets Dimensions**


Here are shown body gaskets dimensions installed on valves.



	150÷800			1500c			1500÷2500			
	lg	Eg	Hg	lg	Eg	Hg	la	Ma	Ea	Ha
1/2"R	31	39,5	3,5	28	37,5	3,5	-	-	-	-
3/4"R	31	39,5	3,5	31	39,5	3,5	-	-	-	-
1"R	40	48,5	3,5	36	45,5	3,5	-	-	-	-
1.1/4"R	42	53,5	3,5	42	53,5	3,5	-	-	-	-
1.1/2"R	50	62,5	3,5	50	62,5	3,5	-	-	-	-
2"R	58	71,5	3,5	58	71,5	3,5	-	-	-	-
1/4"F	31	39,5	3,5	-	-	-	-	-	-	-
3/8"F	31	39,5	3,5	-	-	-	-	-	-	-
1/2"F	31	39,5	3,5	-	-	-	31,8	39,7	47,6	12,7
3/4"F	40	48,5	3,5	-	-	-	39,7	47,6	55,6	12,7
1"F	42	53,5	3,5	-	-	-	42,9	50,8	58,7	12,7
1.1/4"F	50	62,5	3,5	-	-	-	-	-	-	-
1.1/2"F	58	71,5	3,5	-	-	-	62,9	74,0	85,1	15,9
2"F	74,5	87,5	4,5	-	-	-	62,9	74,0	85,1	15,9

**10.2) Packings Dimensions**

Here are shown packings dimensions installed on valves.




	150÷800			1500c			1500			2500		
	lb	Eb	Hb	lb	Eb	Hb	lb	Eb	Hb	lb	Eb	Hb
1/2"R	9,5	16	18	11,1	17,5	24	-	-	-	-	-	-
3/4"R	9,5	16	18	11,1	17,5	26	-	-	-	-	-	-
1"R	11,1	17,5	26	14,3	24	30	-	-	-	-	-	-
1.1/4"R	12,7	20	28	15,9	29	30	-	-	-	-	-	-
1.1/2"R	15,9	26	30	15,9	26	30	-	-	-	-	-	-
2"R	15,9	26	30	19,0	29	35	-	-	-	-	-	-
1/4"F	9,5	16	18	-	-	-	-	-	-	-	-	-
3/8"F	9,5	16	18	-	-	-	-	-	-	-	-	-
1/2"F	9,5	16	18	-	-	-	12,7	22	34	14,3	24	35
3/4"F	11,1	17,5	26	-	-	-	15,9	26	40	19,0	29	40
1"F	12,7	20	27	-	-	-	15,9	26	40	19,0	29	40
1.1/4"F	15,9	26	30	-	-	-	-	-	-	-	-	-
1.1/2"F	15,9	26	30	-	-	-	22,2	34	54	22,2	34	54
2"F	19,0	39	35	-	-	-	22,2	34	54	25,4	38	58

### 10.3) Pneumatic and Hydraulic Tests

Here are shown the tight final test and pressure values that can be applied on valves.


#### 10.3.1) Gate Valves

- S1 - Seat tight Test
- S2 - Body tight Test
- S3 - Backseat tight Test (with ranged Gland Nuts)



#### 10.3.2) Globe Valves


- D1 - Seat tight Test
- D2 - Body tight Test
- D3 - Backseat tight Test (with ranged Gland Nuts)



10.3.3) Check Valves


R1 - Seat tight Test

R2 - Body tight Test




10.3.4) Quick Opening Globe Valves

Q1 - Seat tight Test



Q2 - Body tight Test



10.3.5) Applicable Pressure Tests

Here are shown the pressure values applicable for final tight tests of valves.

	<b>S1 - D1 - R1</b>		<b>S2 - D2 - R2</b>		<b>S3 - D3</b>	
	<i>Bar</i>	<i>PSI</i>	<i>Bar</i>	<i>PSI</i>	<i>Bar</i>	<i>PSI</i>
<b>150</b>	<b>22</b>	<b>319</b>	<b>30</b>	<b>435</b>	<b>22</b>	<b>319</b>
<b>300</b>	<b>57</b>	<b>826</b>	<b>78</b>	<b>1131</b>	<b>57</b>	<b>826</b>
<b>600</b>	<b>114</b>	<b>1653</b>	<b>156</b>	<b>2262</b>	<b>114</b>	<b>1653</b>
<b>800</b>	<b>155</b>	<b>2247</b>	<b>211</b>	<b>3059</b>	<b>155</b>	<b>2247</b>
<b>900</b>	<b>171</b>	<b>2479</b>	<b>233</b>	<b>3378</b>	<b>171</b>	<b>2479</b>
<b>1500</b>	<b>285</b>	<b>4132</b>	<b>388</b>	<b>5626</b>	<b>285</b>	<b>4132</b>
<b>2500</b>	<b>475</b>	<b>6887</b>	<b>647</b>	<b>9381</b>	<b>475</b>	<b>6887</b>
<b>4500</b>	<b>855</b>	<b>12400</b>	<b>1165</b>	<b>16897</b>	<b>855</b>	<b>12400</b>

## 10.4) Limits of Working



For safety reasons, the limits of working pressure/temperature for each class of valve and for each material are stated on the PMA and on the Identification Nameplates put on the valves.

In every case, the limits stated on 3 tables attached, must be mandatory followed.

No exception is allowed.

**The Manufacturer will not be liable if the stated limits will not be followed by the User.**

### Nickel Steels

	Cl. 150		Cl. 300		Cl. 600		Cl. 800		Cl. 900		Cl. 1500		Cl. 2500		Cl. 4500	
<b>Maximum Working Pressure BAR</b>																
UNS N05500																
<b>Maximum Working Pressure BAR</b>	20	5,5	51,8	35,3	104	70,2	138	93,7	155	105	258,5	175	430,9	291,6	775,6	524,6
UNS N10675	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426
<b>Maximum Working Pressure BAR</b>	15,9	9,7	41,5	24,9	83	49,8	111	66,4	155	39,6	258,5	50,6	430,9	84,1	775,6	151,6
UNS N06022	-198	676	-198	676	-198	676	-198	676	-198	676	-198	676	-198	676	-198	676
<b>Maximum Working Pressure BAR</b>	15,9	9,7	41,5	24,9	83	49,8	111	66,4	155	39,6	258,5	50,6	430,9	84,1	775,6	151,6
UNS N10276	-198	676	-198	676	-198	676	-198	676	-198	676	-198	676	-198	676	-198	676
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	12,8	104	25,6	138	34,2	155	38,2	258,5	63,7	430,9	106,5	775,6	191,3
UNS N06625	-198	648	-198	648	-198	648	-198	648	-198	648	-198	648	-198	648	-198	648
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	25,2	104	50,1	138	67,1	155	75,1	258,5	125	430,9	208,9	775,6	375,7
UNS N08825	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	20	5,5	51,8	35,3	104	70,2	138	93,7	155	105	258,5	175	430,9	291,6	775,6	524,6
UNS N10665	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426
<b>Maximum Working Pressure BAR</b>	15,9	1,4	41,5	25,2	83	50,2	111	67	124	75,1	206,8	125	344,7	208,9	620,5	375,7
UNS N08810	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	19	1,4	49,8	25,2	99,6	50,1	133	67	149	75,1	248	125	413,6	208,9	744,6	375,7
UNS N08800	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	14,8	104	29,7	138	39,7	155	44,8	258,5	74,4	430,9	124,1	775,6	223,3
UNS N06600	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	15,9	3,5	41,5	17	83	34,2	111	45,5	124	51	206,8	85,1	344,7	141,6	620,5	255,4
UNS N04400	-198	482	-198	482	-198	482	-198	482	-198	482	-198	482	-198	482	-198	482
Material / Maximum Working Pressure	Minimum Temperature °C															
	Maximum Temperature °C															
	Minimum Temperature °C															
	Maximum Temperature °C															
	Minimum Temperature °C															
	Maximum Temperature °C															
	Minimum Temperature °C															
	Maximum Temperature °C															
	Minimum Temperature °C															
	Maximum Temperature °C															

**Carbon Steels, Low Alloys, Austenitic, Martensitic and Ferritic-Austenitic Steels**

	Cl. 150		Cl. 300		Cl. 600		Cl. 800		Cl. 900		Cl. 1500		Cl. 2500		Cl. 4500	
<b>Maximum Working Pressure BAR</b>																
UNS S32550																
<b>Maximum Working Pressure BAR</b>	19,7	5,5	51,2	28,3	102	57	136	75,9	153	85	255,4	142	425,4	236,5	766	425,4
Gr. 4130 (UNS G41300)	-29	426	-29	426	-29	426	-29	426	-29	426	-29	426	-29	426	-29	420
<b>Maximum Working Pressure BAR</b>	17	9,7	44,3	29,7	88,5	59,8	118	79,6	132	84,8	221	141	368,1	235,8	662,5	424,3
UNS N08904	-198	371	-198	371	-198	371	-198	371	-198	371	-198	371	-198	371	-198	371
<b>Maximum Working Pressure BAR</b>	15,9	5,5	41,5	33,9	83	67,8	111	90,3	155	105	258,5	175	430,9	291,6	775,6	524,6
UNS N08020	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426
<b>Maximum Working Pressure BAR</b>	20	9,7	51,8	38,4	104	77,1	138	103	155	115	258,5	192	430,9	319,9	775,6	575,7
ASTM A182/F44 - F51 - F53 - F55	-50	315	-50	315	-50	315	-50	315	-50	315	-50	315	-50	315	-50	315
<b>Maximum Working Pressure BAR</b>	19	1,4	49,8	25,3	99,6	50,1	132	66,9	149	75,2	248,2	126	413,7	208,9	775,6	435
ASTM A182/F347 - F347H	-198	537	-198	537	-235	537	-235	537	-235	537	-235	537	-235	537	-235	537
<b>Maximum Working Pressure BAR</b>	19	1,4	49,8	24,5	99,6	49,4	132	65,5	149	73,8	248,2	123	413,7	204,8	775,6	435
ASTM A182/F321 - F321H	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	15,9	4,5	41,5	22,1	83	44,6	110	59,3	124	66,5	206,8	111	344,7	184,8	620,5	332,6
ASTM A182/F304L - F316L	-198	454	-198	454	-198	454	-198	454	-198	454	-198	454	-198	454	-198	454
<b>Maximum Working Pressure BAR</b>	19	1,4	49,8	2,8	99,6	5,9	132	7,6	149	8,6	248,2	14,1	413,7	23,7	744,6	42,7
ASTM A182/F316H	-198	815	-198	815	-198	815	-198	815	-198	815	-198	815	-198	815	-198	815
<b>Maximum Working Pressure BAR</b>	19	1,4	49,8	24,2	99,6	48,4	132	64,5	149	75,2	248,2	126	413,7	208,9	744,6	361,6
ASTM A182/F316	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	19	0,7	49,8	1,7	99,6	3,8	132	4,8	149	5,5	248,2	9,3	413,7	15,8	744,6	28,2
ASTM A182/F304H	-198	815	-198	815	-198	815	-198	815	-198	815	-198	815	-198	815	-198	815
<b>Maximum Working Pressure BAR</b>	19	1,4	49,8	22,1	99,6	44,2	132	59	149	66,5	248,2	111	413,7	185,1	744,6	331,9
ASTM A182/F304	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	25,2	104	48,8	138	67	155	75,1	258,5	125	430,9	208,9	775,6	375,7
ASTM A182/F91	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	18	104	36	138	47,9	155	55,5	258,5	92,4	430,9	153,8	775,6	269,5
ASTM A182/F22	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	14,8	104	29,7	138	39,7	155	46,2	258,5	76,9	430,9	126,2	775,6	223,3
ASTM A182/F11	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	17,6	104	34,9	138	46,6	155	60,3	258,5	101	430,9	167,5	775,6	262,3
ASTM A182/F9	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	13,8	104	27,6	138	36,6	155	39,6	258,5	66,2	430,9	110,3	775,6	205,8
ASTM A182/F5	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537	-29	537
<b>Maximum Working Pressure BAR</b>	18,3	4	48	32,3	96,1	64,8	128	86,4	143	101	239	168	398,8	279,9	718	503,6
ASTM A182/F1	-29	468	-29	468	-29	468	-29	468	-29	468	-29	468	-29	468	-29	468
<b>Maximum Working Pressure BAR</b>	20	7,6	51,8	39,4	104	78,5	138	99	155	112	258,5	187	430,9	310	775,6	559
ASTM A182/F6a Cl. 1-2-3-4 - AISI 410	-29	371	-29	371	-29	371	-29	371	-29	371	-29	371	-29	371	-29	371
<b>Maximum Working Pressure BAR</b>	19,7	5,5	51,2	28,3	102	57	136	75,9	153	85	255,4	142	425,4	236,5	766	425,4
ASTM A350/LF2	-46	426	-46	426	-46	426	-46	426	-46	426	-46	426	-46	426	-46	426
<b>Maximum Working Pressure BAR</b>	19,7	5,5	51,2	28,3	102	57	136	75,9	153	85	255,4	142	425,4	236,5	766	425,4
ASTM A105N	-29	426	-29	426	-29	426	-29	426	-29	426	-29	426	-29	426	-29	426
<b>Material / Maximum Working Pressure</b>	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C

**Cast Steels**

	Cl. 150		Cl. 300		Cl. 600		Cl. 800		Cl. 900		Cl. 1500		Cl. 2500		Cl. 4500	
<b>Maximum Working Pressure BAR</b>	15,9	9,7	41,3	24,8	82,7	49,6	110,6	90,2	124	74,4	206,8	124	344,7	206,8	620,5	372
ASTM A351/CN7M	-198	315	-198	315	-198	315	-198	315	-198	315	-198	315	-198	315	-198	315
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	25,2	103,7	50,1	111	67	124	75	206,8	125,4	344,7	208,9	620,5	375,7
ASTM A494/CU5MCuC	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	17,5	11	46,2	29	92,4	58	123	77,2	138,6	86,9	231	145,2	385	241,8	693	435
ASTM A494/CW-12MW	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	20	1,4	51,8	14,8	103,7	29,7	138	39,7	154	44,8	259	74,5	431	124	776	223
ASTM A494/CW-6MC	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537	-198	537
<b>Maximum Working Pressure BAR</b>	20	5,5	51,8	35,2	104	70	138	93,4	154	105,2	259	175	431	291	776	525
ASTM A494/CY-40	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426	-198	426
<b>Maximum Working Pressure BAR</b>	15,9	3,5	41,5	17	83	34,2	110,6	45,5	124	51	206,8	85,1	344,7	141,6	620,5	255,4
ASTM A494/M35-1	-198	482	-198	482	-198	482	-198	482	-198	482	-198	482	-198	482	-198	482
Material / Maximum Working Pressure	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C	Minimum Temperature °C	Maximum Temperature °C

## 10.5) CV Values

CV values:

DOUGLAS CHERO Valves												
Flow Coefficient ( C <sub>v</sub> )												
	GATE		GLOBE			PISTON Ch.			BALL Ch.		SWING Ch.	
	Red.	Full	Red.	Full	"Y" Full	Red.	Full	"Y" Full	Red.	Full	Red.	Full
<b>Class 150-300-600</b>												
1/2"			1,5	3,5	-			-				
3/4"			3,2	5,5	-			-				
1"			6,2	9,5	-			-				
1.1/2"			19,0	21,0	-			-				
2"			21,5	38,0	-			-				
<b>Class 800</b>												
1/4"	-	2,6	-	0,8	-	-	0,8	-	-	0,8	-	-
3/8"	-	5,6	-	0,8	-	-	0,8	-	-	0,8	-	-
1/2"	6,2	12,2	1,6	3,0	4,3	1,2	2,6	4,0	1,2	2,6	3,4	6,2
3/4"	10,0	22,8	3,6	6,0	11,1	3,2	5,0	8,0	3,2	5,0	7,0	13,4
1"	25,8	44,0	7,4	11,2	13,8	5,8	12,0	11,8	5,8	12,0	14,2	19,0
1.1/4"	44,6	56,2	10,2	15,8	20,6	9,6	13,6	18,8	9,6	13,6	20,4	28,6
1.1/2"	68,7	98,8	16,2	18,4	37,0	13,0	16,0	36,0	13,0	16,0	30,2	57,4
2"	99,0	198,0	20,0	35,4	68,0	17,0	31,0	62,4	17,0	31,0	56,2	104,2
<b>Class 1500c</b>												
1/2"	8,8	-	3,2	-	-	2,6	-	-	2,6	-	4,4	-
3/4"	18,4	-	4,4	-	-	4,2	-	-	4,2	-	9,8	-
1"	34,0	-	6,8	-	-	6,0	-	-	6,0	-	17,2	-
1.1/4"	46,6	-	10,2	-	-	9,8	-	-	9,8	-	27,4	-
1.1/2"	56,6	-	18,0	-	-	17,8	-	-	17,8	-	52,0	-
2"	78,2	-	26,8	-	-	22,0	-	-	22,0	-	76,4	-
<b>Class 1500</b>												
1/2"	-	9,0	-	3,4	5,4	-	2,8	4,0	-	2,8	-	4,6
3/4"	-	18,6	-	4,8	11,2	-	4,6	10,6	-	4,6	-	10,2
1"	-	34,8	-	7,2	14,8	-	6,2	17,0	-	6,2	-	17,6
1.1/4"	-	-	-	-	-	-	-	-	-	-	-	-
1.1/2"	-	58,6	-	19,6	35,0	-	19,4	45,4	-	19,4	-	56,4
2"	-	83,8	-	29,4	68,0	-	24,8	74,0	-	24,8	-	81,8
<b>Class 2500</b>												
1/2"	-	8,2	-	2,8	2,9	-	2,4	4,0	-	2,4	-	4,0
3/4"	-	17,8	-	4,0	5,8	-	3,6	6,6	-	3,6	-	6,2
1"	-	32,0	-	6,4	12,1	-	5,8	10,2	-	5,8	-	11,2
1.1/4"	-	-	-	-	-	-	-	-	-	-	-	-
1.1/2"	-	57,4	-	17,2	27,0	-	15,8	32,0	-	15,8	-	48,4
2"	-	74,8	-	26,4	36,0	-	24,0	57,6	-	24,0	-	70,0

The flow characteristic of a valve is identified by means of the C<sub>v</sub> symbol.  
 Values in U.S. gallons per minute of Water at 60°F (with differential pressure of 1 psi and with valve completely open).  
 C.V. factor in U.S.A. GALLON (US liquid)=3,78541 litre.

$$C_v = \frac{Q}{\sqrt{\frac{\Delta p}{S}}}$$

where: Δp= Pressure drop (p.s.i)  
 Q= Liquid flow in gallons per minute  
 S= Specific gravity of liquid relative to water (Water=1)  
 C<sub>v</sub>= Valve flow coefficient

Rev.7 - Date Sep. 04, 1997



## 11) INSTRUCTION FOR USE OF THE VALVES IN POTENTIALLY EXPLOSIVE ATMOSPHERES (ATEX)

In addition to all indications, recommendations and procedures reported at the section 1) to 10) of this Instruction Manual, for valves operating Potentially Explosive Atmospheres, according to the European Directive 94/9/CE "ATEX", the user must respect all the instructions of the following section 11).

### 11.1) Service Temperature

**Risk rising by the temperature of the valve exterior surfaces.**

The temperature of the exterior surface of the valves is generated by the temperature of the process fluid.

User must ensure that the risk of hot surfaces is duly considered, when the valves are operating in potentially explosive atmospheres.

The valves can not be used at a service temperature exceeding the maximum temperature stated by the temperature class, to be specified at care of the user.

Temperature class are the following:

Temperature Class	Valve Surface Maximum Temperature (°C)
T1	450
T2	300
T3	200
T4	135
T5	100
T6	85

**When the user do not give any indication of the temperature class, the valves must be used according to the limit of material, within the maximum temperature stated in the section 10.4 of this Instruction Manual.**

### 11.2) Opening and Closing Operations of Manual Valves

#### 11.2.1) Risk for hot temperature due to the friction between stem and yoke nut of the manual valves during the opening/closing operations

There is no risk due to the friction between stem and yoke nut, since the negligible speed involved in operations, can not generate any hot surface temperature.

The maximum speed of the rotating components (maximum stroke) of manual valves is 60 mm./Minute (30 revolution per minute).

Document <b>MI/B-0294/EN</b>	Rev. <b>05</b>	Section: <b>11 - Instruction for use of the valves in Potentially Explosive Atmospheres (ATEX)</b>	Sheet / of <b>1 / 4</b>	Version: <b>ENGLISH</b>
---------------------------------	-------------------	---	----------------------------	----------------------------

For the rotating parts involved, suitable materials are selected (Percentage of Magnesium < 7,5 %).

### **11.2.2) Risk for hot temperature due to the friction between stem and yoke nut of tool operated valves**

There is no risk of hot temperature for friction between stem and yoke nut.

For the rotating components, suitable materials are selected (Percentage of Magnesium < 7,5 %).

When special tool are used for valve operating (e.g. pneumatic gun or other tools), user must ensure that the maximum rotating speed of the yoke nut and of the stem does not exceed 60 mm./Minute (30 revolution per minute).

### **11.3) Fluid Leakage**

The correct periodical maintenance of gland stuffing box is recommended as per section **6) ORDINARY MAINTENANCE** and if necessary, also section **7) EXTRAORDINARY MAINTENANCE** of this Instruction Manual.

#### **11.3.1) Fluid leakage due to breaking of the stem**

This inconvenience is due to stem over torque by improper tools, used for non manual operating of handwheel.

Several tensile strength tests, performed on the connection yoke/stem/disc, proved that the stress crack have affected in the 95% of cases, the screwed portion of stem and in the 5% of cases, the connection between stem and disc.

Therefore the tightening stem/packing can guarantee no leakage, since takes place in the smooth portion of the stem.

#### **11.4) Opening and Closing Operations of a Motor Operated Valve**

There is no risk due to the friction between stem and yoke nut, since the negligible speed involved in operations, can not generate any hot surface temperature.

The maximum speed of the rotating components of manual valves is 60 mm./Minute (30 revolution per minute).

For the rotating parts involved, suitable materials are selected (Percentage of Magnesium < 7,5 %).

### **11.5) Dust Cleaning-Up**

#### **11.5.1) Risk for dust deposit on valve exterior surfaces**

The shape of valve allows the deposit of dust layers on the flat surfaces of the body.

However all the areas can be easily accessible for cleaning-up.

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>11 - Instruction for use of the valves in Potentially Explosive Atmospheres (ATEX)</b>	<i>Sheet / of</i> <b>2 / 4</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	--	-----------------------------------	-----------------------------------

The exterior surface temperature of the valve is generated by the process fluid temperature.

User must ensure that the risk of the dust over heating is duly considered, when the valves are operating in potentially explosive atmospheres.

Dust must be cleaned-up before the layer thickness exceeds 5 mm.

### **11.5.2) Risk for dust deposit of the electrical ancillary devices of the valve**

When there are electrical equipment fitted on the valve the user must ensure that the dust temperature does not exceed the temperature class of the electrical device (this information must be provided by the user).

Dust must be cleaned-up before the layer thickness exceeds 5 mm.

Dust can be easily cleaned-up from all the accessible parts.

### **11.6) Removal of the Valve Components**

No component of the valve can be removed by accidental operations and without appropriate and suitable tools.

The component removal must be carried out as recommended in **sections 6) ORDINARY MAINTENANCE** and **7) EXTRAORDINARY MAINTENANCE**, by means of proper tools as specified in the **section 9) RESUMING TOOLS LIST** of this Instruction Manual.

### **11.7) Identification of the Equipment**

Besides the identification specified in the section 3) IDENTIFICATION of this Instruction Manual, the valves manufactured in compliance with the Directive 94/9/CE ATEX, have an additional tag with the following marking:

- ATEX
- The description of the equipment
- The **CE** **Ex** markings
- The group II
- The category 2
- The kind of atmosphere G, D or GD (G = Gas/Vapours/Mist // D = Dusts // G/D = Gas/Vapours/Mist/Dusts)
- The temperature class (see section 11.1)
- The number of the technical file of the equipment

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>11 - Instruction for use of the valves in Potentially Explosive Atmospheres (ATEX)</b>	<i>Sheet / of</i> <b>3 / 4</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	--	-----------------------------------	-----------------------------------

**11.8) Safety Instructions for Installation, Operation and Maintenance in Hazardous Area**



The valves belonging to this Instruction Manual are very easy to use.

No special instructions are required for installation, operation and maintenance.

The instructions given at the respective paragraph of this Instruction Manual are deemed exhaustive and complete for a proper usage and good maintenance of said valves

No further instructions or training are required.

There are three binding and mandatory recommendations to follow:

- 1) A complete perusal of this Instruction Manual is recommended, especially at the points marked with  and 
- 2) The execution of Installation, Maintenance and Repairing operations of the valves must be carried out by skilled staff only
- 3) The execution of the operations mentioned at the above point 2) should be performed simultaneously at the perusal of this Instruction Manual

<i>Document</i> <b>MI/B-0294/EN</b>	<i>Rev.</i> <b>05</b>	<i>Section:</i> <b>11 - Instruction for use of the valves in Potentially Explosive Atmospheres (ATEX)</b>	<i>Sheet / of</i> <b>4 / 4</b>	<i>Version:</i> <b>ENGLISH</b>
--	--------------------------	--	-----------------------------------	-----------------------------------